



BATHYSCAPHE 100 GMT

Welcome to the world of AQUADIVE Watches!

This Owner's Guide is designed to help answer any question you might have about the use and care of your Aquadive watch. However, should you need further assistance, or just prefer that "human touch", don't hesitate to contact us!

SAFETY

Keep your watch a safe distance from young children as the edges of the watch and the strap's buckle can scratch a child's skin.

Do not wear your watch while operating machinery with moving parts as your watch could become caught in the gearing.

To ensure proper functioning and timekeeping, please refer to the maintenance manual.



BATHYSCAPHE 100 GMT

MANUAL

GETTING STARTED

OWNERS

P1 NORMAL POSITION

(SCREWED-DOWN, NORMAL OPERATION)

Your **AQUADIVE** is equipped with a screw-in crown that keeps your watch water resistant at depths up to 1000 meters/3300 feet. Please make sure the screw-in crown is screwed down before submerging your watch in water.

The BATHYSCAPHE 100 is equipped with an automatic (self-winding) movement that is wound by the normal movement of your wrist.

Before you wear your **AQUADIVE** for the first time (or after a long period of not wearing your watch), you will need to manually wind it to get it started. IMPORTANT – **NEVER** shake your self-winding watch to get it started. This can damage the movement.

P2 Winding Position

(for manually winding the watch)

To manually wind the watch:

Please unscrew the crown by turning it counterclockwise. It will gently "pop" when the crown has been completely unscrewed. The crown is now in Position 2 (P2). With the crown in Position 2 (P2) please gently turn the crown 30 - 50 times in a clockwise direction. This will sufficiently wind the movement so that it has sufficient power

to begin wearing. Now that you have manually wound the watch, your normal wrist and arm movements will continue to generate power reserve in the watch, literally "self-winding" it. When fully-wound, your **AQUADIVE** should have an average power reserve of 42 hours.

P3 Date & GMT Setting Position

To set the date:

Gently pull the crown once to Position 3 (P3) and turn it anticlockwise to adjust the date.

In months with fewer than 31 days, you will need to manually advance the date at the end of the month.

IMPORTANT - Please do not manually change the date when the hour hand is between 10:00 PM and 2:00 AM. The automatic date function of the watch is actively engaged during this four hour period (the pinions are being repositioned to carry out the automatic date change), and by manually engaging the date while the hour hand in this four hour period it is possible to damage the self-winding movement.



BATHYSCAPHE 100 GMT

GETTING STARTED WITH YOUR

P3 Date & GMT Setting Position

To set the GMT Hand:

Gently pull the crown once to Position 3 (P3) and turn it a clockwise direction to adjust the GMT hand.

If for any reason you are unable to operate the crown of your watch - please contact AQUADIVE customer care immediately.

P4 TIME SETTING POSITION

TO SET THE TIME:

Gently pull the crown to the outermost position (P4) and turn it counterclockwise until you have the correct time. Gently push the crown towards the case until you feel some resistance. Still gently pushing the crown towards the case, turn the crown clockwise (do not apply excessive force!), until the crown is fully screwed down and in Position 1 (P1).

IMPORTANT:

ALWAYS be sure that the crown is fully screwed down. Your watch will NOT be water-resistant if the crown is not completely screwed down and in position 1 (P1). Please note that improper use/operation of the crown will invalidate the warranty.

You can contact AQUADIVE Customer Care department by phone at:

US customer support (888)-397-9363 (3:00-7:00PM)

UK customer support +44 2079936720 (9:00-5:00PM)

EU and ROW customer support +43 660 5482248



AQUADIVE

BATHYSCAPHE 100 GMT

O W N E R S M A N U A L

HRV

The AQUADIVE BATHYSCAPE 100 is equipped with an automatic HRV (Helium Release Valve) at the 6 o'clock position.

(Picture is to show HRV position on 100 model watches and the picture shown is not the 100 GMT model)



AQUADIVE

BATHYSCAPHE 100 GMT

OWNERS MANUAL

WARRANTY

Every AQUADIVE watch is manufactured to exceed the Swiss Made standards - you have our word on it!

Your AQUADIVE watch is covered by a 2 year (24 month) warranty. The warranty is in effect from the date of purchase.

The AQUADIVE warranty covers the watch against manufacturing defects. It specifically excludes damage caused by misuse, accident, or neglect by the owner. It also does not cover any unauthorized service or repair.

The warranty does not cover the strap. AQUADIVE, as the manufacturer, will solely decide whether or not a watch shall be repaired or replaced.

Should your AQUADIVE require servicing during this time period, it shall be serviced and returned to you at no additional cost.

Please email: service@aquadive.com and request an RMA form.

PLEASE – DO NOT SEND YOUR WATCH WITHOUT A COMPLETED AND APPROVED RMA FORM.

You will be given instructions on how to package your watch for shipping, and where to send it.



SERVICE

Your AQUADIVE watch requires regular service to ensure its smooth operation. We recommend a service interval between 3 – 5 years from the date of purchase. With the service interval, your AQUADIVE will be fully disassembled. The movement will be removed, serviced, regulated and lubricated. The gaskets and seals will be removed and replaced with new ones. The watch will be re-sealed and checked for water resistance. The watch will be timed to ensure proper regulation of the movement.

Please contact our service department to arrange a service interval for you AQUADIVE watch.

